



### PCCP x DIP TIE-IN DETAIL

#### NOTES:

1. CONTRACTOR SHALL VERIFY ELECTRICAL ISOLATION OF INSULATING JOINT BEFORE COATING AND BURIAL.
2. DO NOT INSTALL TEST LEAD WIRES AND REFERENCE CELL.
3. APPLICABLE MANUFACTURERS' RECOMMENDATIONS SHALL BE FOLLOWED FOR INSTALLATION OF ADAPTER AND INSULATING FLANGE ASSEMBLIES.

WASHINGTON  
SUBURBAN  
SANITARY  
COMMISSION

APPROVED: 7-26-21

*Mike Harmon*

Chief Engineer

STANDARD DETAIL

PCCP x DIP  
TIE - IN DETAIL  
WITH INSULATING JOINT

C  
3.3