


**NOTES:**

1. WHEN INSTALLING ANODES AT HYDRANTS, ATTACH ONE ANODE TO SHUT-OFF VALVE, AND ONE ANODE LEAD TO HYDRANT RISER PIPE, SEE STD. DETAIL C-5.09.
2. INSTALL ANODES A MINIMUM OF 12 INCHES FROM PIPE.
3. BACKFILL ANODES WITH NATIVE SOIL FOR A MINIMUM OF 12 INCHES ON ALL SIDES. DO NOT BACKFILL ANODES WITH SAND OR STONE.
4. DO NOT THERMITE WELD TO PVC PIPE.

WASHINGTON SUBURBAN SANITARY COMMISSION	APPROVED: <u>7-26-21</u>  Chief Engineer	STANDARD DETAIL PVC MAIN MULTIPLE ANODE PLACEMENT	$\frac{C}{7.14}$
--	---	---	------------------