



NOTES:

- 1. USE INSULATORS ON 1", 1 1/2", AND 2" COPPER PIPE HOUSE CONNECTIONS.
- 2. USE INSULATOR ON COPPER PIPE TAPPED ON CAST IRON OR DUCTILE IRON PIPES,

WASHINGTON SUBURBAN SANITARY COMMISSION APPROVED: 7-26-21

Mill Harrier

Chief Engineer

STANDARD DETAIL

INSULATED JOINT FOR COPPER PIPE SERVICE CONNECTIONS (2" OR LESS) 3.5